

April 2026

Release Notes

All rights reserved, including intellectual property rights. Technical data subject to modifications and delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner.

Copyright © 2026 Fujitsu

The Fujitsu brand and the Fujitsu logo are registered trademarks of Fujitsu Limited, Japan in Europe and other countries.

BS2000 is a trademark of Fujitsu Germany GmbH in Europe.

1 General	3
1.1 Ordering	3
1.2 Delivery	3
1.3 Documentation	3
2 Support matrix	4
2.1 FC switches - Fabric OS (FOS) V8.x	4
2.2 FC switches - Fabric OS (FOS) V9.x	5
3 Technical information	6
3.1 Software configuration	6
3.2 BS2000 specific settings	6
3.3 Restrictions	6
3.4 Procedure in the event of errors	6
3.5 Discontinued functions (and those to be discontinued)	6
4 Hardware requirements	7
4.1 Server Units for SE Servers	7

1 General

These release notes supplements the release notes for the FC switches and FOS versions and contains a list of the FC switches and FOS versions supported by BS2000 as well as dependencies and operating instructions for connecting FC switches to BS2000 servers.

*20 **The release level is of: April 2026.**

*20 Changes to release level March 2026 are marked with *20
*19 Changes to release level November 2025 are marked with *19
*18 Changes to release level August 2025 are marked with *18
*17 Changes to release level June 2025 are marked with *17
*16 Changes to release level June 2024 are marked with *16
*15 Changes to release level November 2023 are marked with *15
*14 Changes to release level September 2023 are marked with *14
*13 Changes to release level March 2023 are marked with *13
*12 Changes to release level August 2022 are marked with *12
*11 Changes to release level January 2022 are marked with *11
*10 Changes to release level October 2021 are marked with *10
*09 Changes to release level July 2021 are marked with *09
*08 Changes to release level May 2021 are marked with *08
*07 Changes to release level April 2021 are marked with *07
*06 Changes to release level August 2020 are marked with *06
*05 Changes to release level February 2020 are marked with *05
*04 Changes to release level July 2019 are marked with *04
*03 Changes to release level February 2018 are marked with *03
*02 Changes to release level October 2017 are marked with *02
*01 Changes to release level August 2017 are marked with *01

*03 This and further ongoing release notes are available online by <http://bs2manuals.ts.fujitsu.com>.

Additionally, the following release notes must be taken into account (depending on the installed software):

*06 BS2000 OS DX

1.1 Ordering

The purchase of the FC switches can be ordered in general via your local distributor.

1.2 Delivery

-

1.3 Documentation

*11 The documentation is also available on the internet at <https://bs2manuals.ts.fujitsu.com>.
*11 There you will find both individual manuals and (under the „SoftBooks“ tab) the ISO
*11 image of a DVD with the entire inventory.

*05 Please ask your service provider for the current FC switch documentation.

See the support sites of your service provider for the announced “End-of-Life” dates.

2 Support matrix

2.1 FC switches - Fabric OS (FOS) V8.x

	Brocade FC Switch						Remarks	
	16G	32G						
	6520	G610	G620	G630	X6-4	X6-8		
FOS v8.x.x (Release date for BS2000)								
*20	8.2.3a2 (10.01.2022)							N
*20	8.2.3c1 (24.02.2023)							N
*20	8.2.3d (08.09.2023)							N
*20	8.2.3f (08.04.2026)	X						

X: supported

*20 N: FOS v8.2.3f is the only FOS v8.x version that is currently supported by the manufacturer.

2.2 FC switches - Fabric OS (FOS) V9.x

	Brocade FC Switch									Remarks
	32G					64G				
	G610	G620	G630	X6-4	X6-8	G720	G730	X7-4	X7-8	
FOS v9.x.x (release date for BS2000)										
*17	9.2.1b (08.08.2025)	X	X	X	X	X	X	X	X	
*17	9.2.2a (08.08.2025)	X	X	X	X	X	X	X	X	
*18	9.2.2b (26.11.2025)	X	X	X	X	X	X	X	X	
*19	9.2.2c (03.03.2026)	X	X	X	X	X	X	X	X	

X: supported

3 Technical information

3.1 Software configuration

Support is granted for SE Server from BS2000 OS DX V1.0B.

3.2 BS2000 specific settings

-

3.3 Restrictions

In BS2000 environment no tests with any fabric/switch monitoring software have been conducted.

3.4 Procedure in the event of errors

In case of hardware or firmware errors, please contact your local Service provider.
If a general error occurs in BS2000, please pay attention to the respective instructions in the BS2000 release notes.

3.5 Discontinued functions (and those to be discontinued)

*20 Starting from M2000 Version 6.7: The FC Switch continues to be supported in this version;
*20 however, it can no longer be managed via the SEM web interface. Existing switches will
*20 no longer be updated and will appear unreachable in SEM.

4 Hardware requirements

*16 SE Server: SE740, SE730, SE730B, SE710, SE340, SE330, SE330B, SE320,
SE310

4.1 Server Units for SE Servers

*16 SU740:
*16 - 64Gb FC channel

*15 SU730B:
*15 - 16Gb FC channel

*13 SU730:
*13 - 16Gb FC channel

*04 SU710:
*04 - 16Gb FC channel

*16 SU340:
*16 - LPe35002
*16 - LPe31002
*16 - LPe36002

*15 SU330B:
*15 - LPe31002
*15 - LPe35002
*20 - LPe36002

*13 SU330:
*13 - LPe31002
*13 - LPe35002

*06 SU320:
*06 - LPe35002

*04 SU310:
*04 - LPe31002
*04 - LPe32002