

**Fujitsu Software BS2000 X2000**

Version 6.6A

October 2024



## Release Notice

---

All rights reserved, including intellectual property rights. Technical data subject to modifications and delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner.

Copyright © 2024 Fujitsu

The Fujitsu brand and the Fujitsu logo are registered trademarks of Fujitsu Limited, Japan in Europe and other countries.

BS2000 is a trademark of Fujitsu Germany GmbH in Europe.

<b>1</b>	<b>General information</b>	<b>3</b>
1.1	Ordering	3
1.2	Delivery	3
1.3	Documentation	4
<b>2</b>	<b>Software extensions</b>	<b>5</b>
<b>3</b>	<b>Technical information</b>	<b>6</b>
3.1	Resource requirements	6
3.2	Software configuration	8
3.3	Product installation	8
3.4	Product use	8
3.5	Obsolete (and discontinued) functions	10
3.6	Incompatibilities	10
3.7	Restrictions	10
3.8	Procedure in the event of errors	10
<b>4</b>	<b>Hardware requirements</b>	<b>11</b>
<b>5</b>	<b>Firmware levels</b>	<b>12</b>

# 1 General information

This Release Notice is a summary of the major extensions, dependencies and operating information about the delivery components of the Fujitsu software BS2000 X2000 V6.6A.

Together with the Linux operating system, X2000 V6.6A serves on the Intel x86\_64 architecture based Server Unit (SU x86) SU340, SU330/B, SU320 and SU310 as the carrier system for BS2000.

X2000 V6.6A provides the functions for operating and administering the hardware for the BS2000 operating systems.

**The contents correspond to the release level of October 2024.**

The current release corresponds to the following delivery releases:  
X2000 V6.6A0106                      Release 09.2024

The Release Notice is shipped on the docu CD.

The following Release Notices must also be taken into consideration for X2000 V6.6A:

M2000 V6.6A  
BS2000 OS DX V1.0B  
VM2000 V12.0B

This and other current Release Notices are available online:

<https://bs2manuals.ts.fujitsu.com/>

If one or more previous upgrades are skipped when this product version is used, then the information from the Release Notices (and README files) for these previous versions must also be taken into account.

## 1.1 Ordering

The software X2000 V6.6A is supplied preinstalled as a component of a SE Server with SU x86 and cannot be ordered separately.

## 1.2 Delivery

The software X2000 is part of a SE Server with SU x86 and is either supplied pre-installed on the Server Units or will be installed on an already delivered SU x86 by Fujitsu service.

The X2000 V6.6A files are delivered along with the hardware delivery as DVD media.

### 1.3 Documentation

The following manuals are part of the SE server documentation:

- SE specific manuals which describe concepts and the operation of a server of the SE series:
  - Fujitsu Server BS2000 SE Series Administration and Operation
  - Fujitsu Server BS2000 SE Series Quick Start Guide
  - Fujitsu Server BS2000 SE Series Security Manual
  
- White paper
  - Fujitsu Server BS2000 SE Series Cluster Solutions for SE Server
  
- Operating manual Fujitsu Server BS2000 SE series comprising the following modules
  - Fujitsu Server BS2000 SE Series Basic Operation Manual
  - Fujitsu Server BS2000 SE Series Operation Manual Server Unit /390
  - Fujitsu Server BS2000 SE Series Operation Manual Server Unit x86
  - Fujitsu Server BS2000 SE Series Operation Manual Additive Components

The documentation is available on the Internet at <https://bs2manuals.ts.fujitsu.com/>. There you will find both individual manuals and (under the "Softbooks" tab) the ISO image of a DVD with the entire inventory.

The corresponding HW documentation is required in order to use the HW peripheral devices.

## 2 Software extensions

X2000 V6.6A is a further development of X2000 V6.5A SP2 and offers the following main extensions and enhancements compared to the previous version:

- **Rebasing on SLES 15 SP5**  
The basic system of the Linux appliance X2000 was rebased on SUSE Linux Enterprise Server 15 SP5.
- **Support of a new high-end x86-64 system as HW base for SU340**  
A high-end x86-64 server with Intel® Xeon® Platinum 8444H processors is supported as the new HW basis for SU x86 with increased BS2000 monoproccessor performance (model designation “SE SERVER SU340 M1”)
- **Entry-level model SE340 with SSDs for BS2000 disks**  
As an entry-level model, the SU340 is also offered with internal SSD disks for BS2000 disks. These disks are emulated in so-called EMDISC containers. The EMDISC containers are configured by Fujitsu Service.  
No external disk peripherals for BS2000 are required for this entry-level model.

### 3 Technical information

#### 3.1 Resource requirements

Main memory requirements:

##### Model line SU310

SU x86 model	BS2000 processors	Main memory (GB) basic configuration / guest systems / BS2000 without JIT	PCIe slots
SU310-10R	1	128 / 96 / 58	6
SU310-10	1	128 / 96 / 58	6
SU310-20	2	128 / 96 / 58	6

##### Model line SU320

SU x86 model	BS2000 processors	Main memory (GB) basic configuration / guest systems / BS2000 without JIT	PCIe slots
SU320-120	12	512 / 480 / 288	9

##### Model line SU330

SU x86 model	BS2000 processors	Main memory (GB) *basic configuration / guest systems / BS2000 without JIT	PCIe slots
SU330-10A, -10B, -10C, -10D, -10E, -10F	1	128 / 96 / 58	9
SU330-20	2	128 / 96 / 58	9
SU330-40	4	128 / 96 / 58	9
SU330-80	8	128 / 96 / 58	9
SU330-120	12	128 / 96 / 58	9
SU330-160	16	128 / 96 / 58	9

\* The SU330 can be equipped either with 128GB or 512GB main memory

**Model linie SU330B**

<b>SU x86 model</b>	<b>BS2000 processors</b>	<b>Main memory (GB) * basic configuration/ guest systems / BS2000 without JIT</b>	<b>PCIe slots</b>
SU330B-10A, -10B, -10C, -10D, - 10E, -10F	1	128 /96 / 58	9
SU330B-20	2	128 /96 / 58	9
SU310B-40	4	128 /96 / 58	9
SU310B-80	8	128 /96 / 58	9
SU310B-120	12	128 /96 / 58	9
SU310B-160	16	128 /96 / 58	9

\* The SU330B can be equipped either with 128 GB, 256 GB or 512GB main memory

**Model linie SU340**

<b>SU x86 model</b>	<b>BS2000 processors</b>	<b>Main memory (GB) * basic configuration/ guest systems / BS2000 without JIT</b>	<b>PCIe slots</b>
SU340-10A, -10B, -10C, -10D, - 10E, -10F	1	128 /96 / 58	9
SU340-20	2	128 /96 / 58	9
SU340-40	4	128 /96 / 58	9
SU340B-80	8	128 /96 / 58	9
SU340B-120	12	128 /96 / 58	9
SU340B-160	16	128 /96 / 58	9

\* The SU340 can be equipped either with 128 GB, 256 GB or 512GB main memory

The required main memory depends on the customer's configuration, especially for the used applications and the number of guest systems.

Calculation base for computing the main memory needed for BS2000 guest systems: Approximately 32 GB is occupied by the firmware of the SU x86. The remaining memory can be used for BS2000 guest systems, whereof approx. 40% is re-quired by JIT.

## 3.2 Software configuration

### BS2000 system versions native and VM2000 mode

- BS2000 native
  - BS2000 OS DX V1.0B
- VM2000 V12.0B
  - BS2000 OS DX V1.0B as monitor or guest system
- Prerequisites for Live Migration (LM):
  - BS2000 OS DX V1.0B
  - VM2000 V12.0 in VM mode

The support of OSD/XC V11.0B is supplied as of SP23.2.

In BS2000 the REPs for A0618376 and A0618377 must be installed on SU340. These REPs are integrated in the service pack SP24.2 and do not need then to be installed separately.

### Linux is not released for use on X2000

The Linux appliance X2000 is a scaled down Linux system exclusively designed to run on the Management Unit of a SE Server. This is why the use of Linux on X2000 is not released for customer applications.

## 3.3 Product installation

The SE Server is delivered with X2000 pre-installed on the Server Units x86. Any new correction levels for X2000 that may be required are supplied as part of the hardware service contract and are installed by Fujitsu service.

## 3.4 Product use

- SE Manager

The operation of X2000 takes place via a web-based GUI called SE Manager running on the Management Unit of the SE Server. The remote operation and administration takes place via PC workplaces that can access the SE Manager on the Management Unit via a web browser.  
For information about supported browsers see release notice for M2000 V6.6A.
- BS2000 operating using the Linux shell

In addition to the terminals which are integrated in the SE Manager, the commands `bs2Console` and `bs2Dialog` are available in the Linux shell of the Management Unit. If called with suitable parameters these commands open the corresponding terminal instances at the specified Server Unit.  
We recommend to use the SSH-client PuTTY for accessing the shell on the Management Unit. You may use PuTTY as of version 0.72.  
If you use a different tool the functionality of `bs2Console` and `bs2Dialog` cannot be guaranteed.  
The use of PuTTY is described in the manual "Fujitsu Server BS2000 SE Administration and Operation".

- Shell commands for the roles operator and BS2000 administrator:  
For accounts of the roles BS2000 operator and BS2000 administrator the connection to BS2000 console, BS2000 dialog and SVP console is possible via the commands `bs2Console` and `bs2Dialog` which are intended to be executed as "remote command" in PuTTY (in case of operator accounts depending on the individual rights). This also applies to the operator and BS2000 administrator roles as sub-roles of a user-defined role.
- Administration commands in X2000 at shell-level  
For a barrier-free administration of the Server Unit, access to the X2000 shell of the SU for the administration account `admin` can be activated by the service. The shell access from the customer network can only be made via a connection to the Management Unit (preferably via PuTTY; see above). The command `ssh -l admin su<nr>-se<ID>.senet` can then be used to switch to the X2000 shell of the SU with the fixed account "admin" (example: The change to the first SU x86 in the SE Server with the ID 1 is done by means of `ssh -l admin su1-se1.senet`). A list of available commands is output by the `cli_info` command. If necessary, the service provides a detailed description of the commands.
- BS2000 hostname  
The minimum length for the bs2000 hostname is 4 characters. The following special characters are supported in principle: #, @  
We recommend not to use special characters.
- Dynamic performance control  
For the use of dynamic performance control, the key "Performance quota" must be installed by the service technician responsible for you.
- ETERNUS DX100 S4 / S5  
Connection is only supported with single path FC direct connection (not via switch) without SHC-OSD. Concerning the port configuration in the storage subsystem, mode "Fabric" has to be chosen as connection mode. For other settings see hints below.
- Maximum values for connecting peripheral devices  
The following maximum configuration is supported for a SU x86 in a SE Server:
  - a maximum of 2048 LUNs on one HBA port
  - a maximum of 2048 LUNs on one RAID controller port
  - a maximum of 8192 BS2000 disks
  - a maximum of 16384 paths may be visible
  - a maximum of 256 MTC devices
  - a maximum of 8 tape devices emulated on file/CD/DVD
  - an overall maximum of 16384 SCSI LUNs per sever unit

#### Hints:

- In order to avoid the maximum of 8192 BS2000 disks or 16384 visible paths respectively being exceeded, disks that are not required should be made invisible in the ETERNUS or Symmetrix system by LUN masking / LUN mapping.
- Tape devices must be configured exclusively at one Server Unit and must not be accessible by a second Server Unit simultaneously. This is to be ensured by suitable actions like LUN masking / mapping.
- Disks and tapes should be connected to different HBA ports of the SU x86.
- Using BS2000 disks of an ETERNUS disk storage system needs the host response profile "BS2000" being activated. Additional information can be found in the document "Fujitsu Storage ETERNUS DX, ETERNUS AF Configuration Guide -Server Connection-" which is available under <https://sp.ts.fujitsu.com/dmosp/Publications/public/p3am-5672-en.pdf>.
- The number of available licenses is displayed in SE Manager's main pages for administering BS2000 devices. Detailed license information is displayed in a tool tip.

- **Inhomogeneous SE cluster**  
An inhomogeneous SE cluster (cluster with one Server running V6.5A SP2 and one Server running V6.6A) is only temporarily released for server innovation and SE SW upgrades.
- **Inhomogeneous SU x86 cluster**  
In an inhomogeneous SU x86 cluster (X2000 V6.5A SP2 - X2000 V6.6A) live migration is only possible from X2000 V6.5A SP2 to X2000 V6.6A as target SU.

### 3.5 **Obsolete (and discontinued) functions**

- none -

### 3.6 **Incompatibilities**

- none -

### 3.7 **Restrictions**

- None -

### 3.8 **Procedure in the event of errors**

For successful diagnostics and elimination of software problems, sufficient error documentation must be created or saved as soon as possible.

If possible, error report documentation should be supplied in the form of files so that it can be analyzed with diagnostic tools. For reproducible errors the user should include detailed information on how to generate the error condition.

#### **Creating X2000 diagnostic data**

##### **In X2000:**

If an error situation occurs, the generation of diagnostic data can be initiated by the administrator or operator via the SE Manager on the Management Unit by way of the "Diagnostics" tab of the menu

Service -> Units (SEnnn) -> <Name> (SU3nn) -> Diagnostics

The file can either be downloaded or sent directly via File Transfer by a member of Fujitsu Service using AIS Connect.

In case of problems which are visible in SE Manager depending on the situation the following diagnostic data should be created:

- meaningful screenshots
- Relevant output at browser's console (text copy or screenshot)

The release notice for M2000 V6.6A contains additional information about creating diagnostic data in SE Manager.

##### **In BS2000:**

- SLED (in case of BS2000 system crash or if the BS2000 system locks up)
- for input/output problems or device error messages HERSFILE and possibly IOTRACE

## **4 Hardware requirements**

X2000 V6.6A is released for the x86 core technology based Server Units SU310, SU320, SU330, SU330B and SU340 of the SE Server series.

## 5 Firmware levels

### Firmware levels of the Server Unit x86 (minimum levels)

The following minimum firmware levels should be used on the Server Units x86 in BS2000 SE Servers. They are installed during system installation in the factory. Any new firmware levels that may be required are installed by Fujitsu service.

SU310 with HW base RX4770 M5

Component	FW version
BIOS	V5.0.0.14 - R1.39.0
iRMC	03.57P_SDR03.28
SAS RAID Ctrl PRAID EP420i	4.680.00-8561
SAS RAID Ctrl PRAID EP540i	5.230.00-3817
Fibre Channel LPe31002 / 32002	14.0.639.18
LAN PLAN EP X710-DA4 4x10Gb SFP+	9.30
LAN PLAN EP X710-T4 4x10GBASE-T	9.30

SU320 with HW base RX4770 M6

Component	FW version
BIOS	V1.0.0.0 - R1.19.0
iRMC	03.57P_SDR03.41
SAS RAID Ctrl PRAID EP540i	5.230.00-3817
Fibre Channel LPe35002	14.0.639.20
LAN PLAN EP X710-DA4 4x10Gb SFP+	9.30
LAN PLAN EP X710-T4 4x10GBASE-T	9.30

SU330 with HW base RX4770 M6

Component	FW version
BIOS	V1.0.0.0 - R1.19.0
iRMC	03.57P_SDR03.41
SAS RAID Ctrl PRAID EP680i	5.230.00-3817
Fibre Channel LPe 31002 / 35002	14.0.639.18 / 14.0.639.20
LAN PLAN EP X710- DA4 / -T4 (10Gb SFP+ / 10GBASE-T)	9.30

## SU330B and SU340 with HW base RX4770 M7

<b>Component</b>	<b>FW version</b>
BIOS	V1.0.0.0 – R2.4.0
iRMC	02.36S_SDR03.23
SAS RAID Ctrl PRAID EP680i	5.260.02-3921
Fibre Channel LPe 31002	14.0.639.18
Fibre Channel LPe 35002 / 36002	14.0.639.20
LAN PLAN EP X710- DA4 / -T4 (10Gb SFP+ / 10GBASE-T)	9.30
LAN-Contr. PLAN EP E810-XXVDA2 / -XXVDA4 (25Gb SFP+)	4.30